

Please observe

Electrical connection

The appliance must only be connected to a properly installed protective contact socket. The installation of the socket or replacement of the connecting cable must only be carried out by a qualified electrician in accordance with current regulations.

The appliance must only be connected with the power cable provided. Connect the power cable to the back of the appliance.

Power cables with various plug types are available from our after-sales service.

Do not use multi-plug adapters, power strips or extension leads. There is a risk of fire in the event of overloading.

If the plug is no longer accessible subsequent to installation, an all-pole disconnecting device must be present on the installation side with a contact gap of at least 3 mm.

Fitted units

There must be no rear wall to fitted units which house appliances. There must be a gap of at least 35 mm between the wall and the base of the unit, as well as between the wall and the rear wall of the unit above.

The ventilation slots and air intake points must not be covered.

To ensure that they remain uncovered, also observe the installation instructions for the appliance above.

Installing the appliance

Connect the appliance to the mains. Then align the appliance flush with the units and screw it in place.

Note: Ensure that the connector lead does not become trapped or bent. After installation, the connector lead must not be in contact with the back or the base of the appliance.

After installation, the connector lead must not be in contact with the back or the base of the appliance.

لطفاً توجه کنید

اتصال به برق

دستگاه باید تنها به سوکت کنتاکت محافظی متصل شود که به درستی نصب شده است. نصب سوکت یا تعویض کابل اتصال باید تنها توسط یک متخصص تعلیم دیده و با رعایت مقررات مربوطه صورت گیرد.

دستگاه باید تنها توسط کابل برق ارائه شده به برق متصل شود. کابل برق را به پشت دستگاه وصل کنید.

کابل های برق دارای دوشاخه های مختلف در مراکز خدمات پس از فروش موجود است.

از چند دوشاخه، ورقه های برق یا کابل خرطومی استفاده نکنید. در صورت بارگذاری بیش از حد خطر آتش سوزی وجود دارد.

اگر دوشاخه برق بعد از نصب دیگر در دسترس نیست، یک گیره قطع کننده به همراه یک شکاف تماس حداقل 3 میلی متری باید روی طرف نصب قرار داشته باشد.

کابینت های مناسب

در کابینت های مناسب دستگاه ها نباید هیچ دیوار پشتی وجود داشته باشد. باید یک شکاف حداقل 35 میلی متری بین دیوار و پایه کابینت و بین دیوار و دیوار پشت کابینت مذکور وجود داشته باشد.

شیراها و ورودی های تهویه نباید مسدود باشد.

برای اطمینان خاطر از اینکه رویشان پوشیده نیست، راهنماهای نصب را برای دستگاه فوق مطالعه بفرمایید.

نصب دستگاه

دستگاه را به دوشاخه های اصلی متصل کنید. سپس فلاش دستگاه را با کابینت ها تراز کنید و آن را در همانجا محکم کنید.

توجه: مطمئن شوید که سیم رابط خمیده یا گیر نکرده باشد. بعد از نصب، سیم رابط نباید با پشت یا پایه دستگاه در تماس باشد.

بعد از نصب، سیم رابط نباید با پشت یا پایه دستگاه در تماس باشد.



